OR EVERY STAGE RED HANDHELD DYNAMIC MICROPHONE R AMBITIOUS PERFORMANCES



II MTP 250 DM/DMs QUICKSTART GUIDE

// Overview

- // Dynamic handheld microphone
- // Cardioid polar pattern for effective isolation of the main sound source
- // Frequency response shaped specifically for vocal applications
- // Integrated acoustic pop and windshield washable
- // Solid full-metal, die-cast body
- // Hardened steel mesh grille
- // Gold plated & corrosion-resistant 3-pin XLR output connector
- // On/Off switch (MTP 250 DMs only)
- Top applications // Vocals, spoken word and live interviews

// Getting started

- 1 Connect your microphone to your mixing console, audio interface or preamp with a 3-pin XLR cable.
- 2 Check the On/Off switch (MTP 250 DMs only).
- 3 Set the input gain on your mixing console, preamp, etc. accordingly.
- **4** To ensure best sound quality, do not cover any part of the grille.
- 5 Rock!

// Please Note

- If To ensure high sensitivity and best sound reproduction of the microphone, avoid exposing it to moisture, dust or extreme temperatures.
- // Do not use force on the switch (MTP 250 DMs only) or cable of the microphone.
- // When disconnecting the microphone cable, grasp the connector and do not pull the cable.
- // Do not attempt to modify or fix the microphone, as it would void your product warranty.
- // The casing of the microphone can be cleaned easily using a wet cloth, never use alcohol or another solvent for cleaning.
- // The integrated acoustic pop and windshield can be washed with soap water, if necessary.



CE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

